



Dispenser Loading Instructions DublServ® Vertical



82300	-	Translucent
82330	-	Red
82340	-	Green
82350	-	Blue
82360	-	White

- To load, simply unlock and open, place a wrapped roll onto the top holder.
- Unwrap a further new roll and place this on the lower holder.

Refilling

- Unlock and open the dispenser. This triggers the dispenser to reset, lifting the roll in use to the top.
- Remove the empty core, move the partly used roll to the bottom feeder and reload the top holder with the new roll.
- Close the cover and the reloaded dispenser is ready to use.